

SPECIFICATION

Power Supply Voltage
Factory set password

12V~30V DC.Negative Ground
“779822”

SPECIFIKATIONER

Spænding
Adgangskode til fabriksindstilling

12V ~ 30V DC, negativ
“779822”

Brugervejledningen af fremstillet af producenten


Produceret af Shenzhen ZY Technology Co., Ltd, Shenzhen,CN
+86 13713968441 , katy@topcarstereos.com
For Autofix.nu, Vejlevej 21, 8722 Hedensted
+45 38414299, support@autofix.nu

10.26" Multimedia

CarPlay/Android Auto(wired & wireless)

CarPlay/Android Auto(kablet og trådløs)

Operation Manual
Brugervejledning



ENGLISH

DANSK

Cigarette lighter power supply
Wireless CarPlay/Android Auto
Wired Mirrorlink
Reversing camera input
Audio/Video/Picture Playback



INSTALLATION METHOD

There are 2 types of brackets, and the installation methods are as follows:

Installation method 1:

Glass suction cup type suspension installation.

Bracket 1




Installation example:



Installation method 2:

Desktop horizontal installation.

Bracket 2



Installation example:



CIGARETTE LIGHTER POWER PLUG

This device is powered by the cigarette lighter power plug.

After the device is installed, insert the power plug of the cigarette lighter into the cigarette lighter, and then it can be turned on for use.



BLUETOOTH PAIRING CONNECTION

You can use Bluetooth music or Bluetooth calls. When using wireless CarPlay, you need to pair the Bluetooth connection first.

Device Bluetooth Name: "CAR-BT"

PIN Number: "0000"

Connection Method:

1. Power on the machine and turn on it.
2. Turn on the Bluetooth function on the mobile phone, click to search for devices, and when the Bluetooth name of the current machine is found, click to connect.

AUDIO OUTPUT METHOD

There are 3 audio output methods:

1. Built-in speaker output sound.

When playing music with a USB flash drive, the sound comes out from the built-in speaker on the back.



Built-in speaker



2. The AUX line is transmitted to the original car player.



AUX line transmission



3.FM transmits sound to the original car radio;

1. Six preset FM transmission frequencies, and then use the original car radio to search for the transmission frequency.

2. Manually set the FM transmission frequency:



FM signal transmission

1. Adjust the original car radio to an empty channel position, such as: "92.3MHz" (to avoid conflicts with local radio interference signals).
2. Set the FM transmission frequency to be consistent with the frequency of the original car, such as: "92.3MHz".
3. At this time, the sound is transmitted to the original car horn.

REVERSING CAMERA CONNECTION(CCD)

The reversing video input can be connected through the RCA adapter cable. When there is a signal at this port, the LCD will automatically switch to the camera image.


1. This wire must be fully inserted and pushed in tightly.
2. Make sure first plug in the reverse detection wire before shift into reverse gear



reverse detection wire

Reverse Video Input

connected Red



If the camera is not installed, please do not connect the REVERSE/BACK cable to any place, otherwise the machine will automatically enter the reverse mode, which will cause the machine to fail.

FUNCTION DESCRIPTION


AV IN (CAM IN)	Video input interface. Connect the reversing camera through the 2.5mm plug RCA cable.
USB Port	You can plug in a USB device to play music, video, and pictures. Mirrorlink, carplay and Android Auto can also be connected through this port.
TF Card	You can insert TF card device to play music, video and pictures.
AUX Out	You can output the sound to other audio equipment through the 3.5mm AUX cable.
DC IN	3.5mm power cord plug the voltage range is 12~30V.
POWER	Power button to power on/off.

Interface Introduction



Mirrorlink(iPhone)

When the device is plugged into the iPhone. the content of the phone screen will be projected onto the car screen.



You can't control your iphone here.

Mirrorlink(Android)


When using an Android device, after connecting the USB data cable, you will be prompted to install the APP software. After installation, plug the data cable again, it will enter the screen mirroring mode. And it can be operated on both the player screen and the phone screen.

Only the image transfer is successful at this time. The sound can only be transmitted after the Bluetooth connection is successful.




You can also control your android phone here.

Apple CarPlay (wired & wireless)




You can also control your iphone here.




1. Wired connection: Just connect the USB data cable, and then it will automatically enter the CarPlay interface.
2. Wireless connection: first turn on the bluetooth and wifi functions of the mobile phone, and then connect the bluetooth. Then it will automatically enter the CarPlay interface. (Note: The signal is transmitted through wifi at this time,so even if the Bluetooth function is turned off, it will be transmitted normally.When the wifi function is turned off, CarPlay will be disconnected.)

Android Auto (wired & wireless)

This feature is not supported in all countries, and "Google Play" services need to be available locally.



[You can also control your android phone here.](#)



1. Need to download and install "Android Auto"  software in "Google Play".
2. A mobile phone with Android 6.0 or higher must be used. Must use a valid data cable connection.
3. Wired connection: Just connect the USB data cable, and then it will automatically enter the Android Auto interface.
4. Wireless connection: First turn on the Bluetooth and wifi functions of the mobile phone, and then connect the Bluetooth. Then it will automatically enter the Android Auto interface. (Note: The signal is transmitted through wifi at this time, so even if the Bluetooth function is turned off, it will be transmitted normally. When the wifi function is turned off, Android Auto will be disconnected.)

COMMON PROBLEMS AND SIMPLE TROUBLESHOOTING

1)How to connect the Mirror Link.

Before connecting the mobile phone,click the phoneLink function of the device,and then select the mode as Mirror,then connect the data cable of the mobile phone,and click the authorization on the mobile phone to connect.

2)How to make the sound come out through the speakers in the car.

- 1.The built-in speaker of our device can emit sound. You can turn it off in the system settings;
- 2.Transmit the sound to the original car radio through the FM transmitting function of the device(for example:select 86.3MHz on the device,and then play USB music,then use the car radio to search for 86.3MHz);
- 3.Transmit the audio to the original car player through the AUX OUT (3.5MM)interface of the machine.

3)Bluetooth not working properly.

Delete the paired"CAR-BT"on the mobile phone,and then re-search the Bluetooth name "CAR-BT".After the pairing is successful,it can be used normally.

4)Can't automatically connect with CarPlay or Android Auto.

- 1.You need to set CarPlay or Android Auto as the default connection mode on the Phonelink setting interface, and then it can automatically jump to the CarPlay or Android Auto interface when USB is connected.

2.If it is a wireless connection, you need to turn on the wifi on the mobile phone, and then when the Bluetooth is connected,it will automatically jump to the CarPlay or Android Auto interface.

5)The sound of playing music or making a phone call is low.

Press and hold your finger on the top of the screen and slide down, pull down the status bar to adjust the playback volume.Return to the main interface during a call, pull down the status bar to adjust the call volume.

6)Can't remember time and date.

The machine does not have a battery, so there is no way to remember the time and date.After connecting to the mobile phone, the time and date will be automatically updated.

7)Can't play TF card, USB music and video.

Use an 8G or 16G USB flash drive or TF card , some devices with larger capacities may not be supported.Format the storage device, use the file system FAT32. Some encoding formats may not be recognized,please use common format media files.

INSTALLATIONSMETODE

To typer af monteringen medfølger:

Installationsmetode 1:

Sugekop monteringen

Beslag 1:




Eksempel på installation:



Installationsmetode 2:

Skrue monteringen

Beslag 2:



Eksempel på installation:



12V Cigaretstik strømforsyning

Denne enhed er drevet af cigarettetænderens strømskik. Når enheden er installeret, indsæt strømskikket i cigarettetænderen, og så kan enheden bruges



OPRET FORBINDELSE VIA BLUETOOTH

Du kan bluetooth musik eller bluetooth opkald. Når du bruger trådløs CarPlay, først skal du have parret din enhed.

Enhedens Bluetooth-navn: "CAR-BT"

PIN-kode: "0000"

Forbindelsesmetode:

1. Tænd skærmen
2. Tænd bluetooth-funktionen på mobiltelefonen, klik for at søge efter enheder, og når bluetooth-navnet på den aktuelle maskine findes, klik for at forbinde.

LYD OUTPUT

Der er 3 lydudgangsmetoder:

1. Indbygget højttaler udgang lyd.



Indbygget højttaler



2. AUX-linjen overføres til den oprindelige lydudgang i bilen



AUX overførsel



3. FM sender lyden til bilens oprindelige lydudgang

- 1). Seks forudindstillede FM-frekvenser, brug derefter den oprindelige bilradio til at søge efter frekvensen.
- 2). Manuel indstilling af FM frekvens



FM-signa
loverførsel


1. Juster den oprindelige bilradio til en tom kanalposition, såsom "92,3 MHz" (for at undgå at være i konflikt med de lokale radiointerferenssignaler)
2. Indstil FM-transmissionsfrekvensen til at være i overensstemmelse med frekvensen i den oprindelige bil, såsom "92,3 MHz".
3. På den måde vil lyden blive flyttet til bilens oprindelige lydudgang

Tilslutning til bakkamera (CCD)

Bakkamera videoindgang kan tilsluttes via RCA-adapterkablet. Når der er et signal på denne port, skifter LCD-skærmen automatisk til kameraet.

1. Bakledningen skal være helt indsat og trykket tæt ind.

2. Sørg for at tilslutte ledningen, før du sætter bilen i bagegear.



Hvis kameraet ikke er installeret, må du ikke tilslutte REVERSE/BACK-kablet nogen steder, da maskinen ellers automatisk går i omvendt tilstand, hvilket vil forårsage maskinens fejl.

Funktionsbeskrivelse


AV IN (CAM IN)	Videoindgang. Tilslut bakkamera gennem 2,5 mm stik RCA kabel.
USB-port	Du kan tilslutte en USB-enhed til at afspille musik, video og billeder. Mirrorlink, carplay eller Android Auto kan også tilsluttes via denne port (kablet)
TF kort	Du kan indsætte TF kort til at afspille gemt musik, video og billeder
AUX out	Du kan sende lyden ud med AUX-kabel via 3,5 mm indgangen
DC in	3,5 mm strømstik, spændingsområdet er 12-30V.
Power tænd /sluk	Strømknapen til at tænde/slukke.

Knapper og input



Mirrorlink (iPhone)

Når enheden er tilsluttet iPhone, vil indholdet af telefonskærmen projiceres på bilskærmen




Du kan ikke styre din iPhone på skærmen

Mirrorlink (Android)


Når du bruger en Android-enhed, efter at have tilsluttet USB-datakablet, vil du blive bedt om at installere APP-softwaren. Efter installation, stik datakablet i igen, herefter vil det gå ind i skærmes spejlingstilstand, og det kan betjenes på både afspillerskærmen og telefonskærmen.

Kun overførslen af billedet er vellykket på dette tidspunkt. Lyden kan kun overføres, når bluetooth-forbindelsen er vellykket.



Du kan også styre din Android-telefon her

Apple CarPlay (kablet og trådløs)




Du kan også styre din iPhone her




1. Kablet forbindelse: Bare tilslut USB-datakabel, og så vil du automatisk tilgå CarPlay brugerfladen.
2. Trådløs forbindelse: Tænd først mobiltelefonens bluetooth- og wifi-funktioner og tilslut derefter bluetooth. Du tilgår automatisk CarPlay-brugerfladen. (Bemærk: Signalet overføres via wifi på dette tidspunkt, så selv bluetooth-funktionen er slukket, vil det overføres normalt. Når wifi-funktionen er slukket, vil CarPlay blive frakoblet.)

Android Auto (kablet og trådløs)

Denne funktion understøttes ikke i alle lande, og Google Play-tjenesterne skal være tilgængelige lokalt.



Du kan også styre din Android-telefon her



1. Behøver at downloade og installere "Android Auto" software i "Google Play"
2. En mobiltelefon med Android 6.0 eller højere er nødvendig. Skal bruge en gyldig datakabelforbindelse.
3. Kablet forbindelse: Bare tilslut USB-datakablet, og så vil du automatisk tilgå Android brugerfladen
4. Trådløs forbindelse: Tænd først mobiltelefonens Bluetooth- og wifi-funktioner, og tilslut derefter bluetooth. Så vil du automatisk tilgå Android Auto brugerfladen. (Bemærk: Signalet overføres via wifi på dette tidspunkt, så selv Bluetooth-funktionen er slukket, vil det overføres normalt. Når wifi-funktionen er slukket, vil Android Auto blive frakoblet.)

Oftest sete problemer og enkel fejlfinding

1) Sådan tilslutter du Mirror Link.

Før du tilslutter mobiltelefonen, klik på enhedens phoneLink-funktion, og vælg derefter tilstanden som spejl, tilslut derefter mobiltelefonens datakabel og klik på autorisationen på mobiltelefonen for at oprette forbindelse.

2) Hvordan man får lyden til at komme ud gennem højttalerne i bilen.

1. Den indbyggede højttaler i vores enhed kan udsende lyd. Du kan slukke det i systemindstillingerne.
2. Send lyden til den oprindelige bilradio gennem enhedens FM-overførselsfunktion (f.eks.: vælg 86,3 MHz på enheden, og afspil derefter musik, brug derefter bilradioen til at søge efter 86,3 MHz).
3. Send lyden til den oprindelige bilafspiller gennem maskinens AUX OUT (3,5 mm)

3) Bluetooth fungerer ikke korrekt.

Slet det parrede "CAR-BT" på mobiltelefonen, og søg derefter igen efter bluetooth-navnet "CAR-BT". Efter parringen er vellykket, kan det bruges normalt.

4) Kan ikke automatisk oprette forbindelse med CarPlay eller Android Auto

1. Du skal indstille CarPlay eller Android Auto som standardforbindelsestilstand på Phonelink-indstillingskærmen, og så kan den automatisk hoppe til CarPlay eller Android Auto-skærmen, når USB er tilsluttet
2. Hvis det er en trådløs forbindelse, skal du tænde for wifi på mobiltelefonen, og når bluetooth er tilsluttet, hopper den automatisk til CarPlay eller Android Auto-skærmen

5) Lyden af at spille musik eller foretage et telefonopkald er lav

Tryk og hold fingeren øverst på skærmen og træk ned, træk statuslinjen ned for at justere afspilningslydstyrken. Tilbage til hovedskærmen under et opkald, træk statuslinjen ned for at justere opkaldets lydstyrke.

6) Kan ikke huske tid og dato.

Maskinen har ikke et batteri, så der er ingen måde at huske tid og dato. Når du har oprettet forbindelse til mobiltelefonen, opdateres tidspunkt og dato automatisk.

7) USB-drev eller TF-kortet kan ikke afspille musik og video.

Brug et 8G eller 16G USB-hdrev eller TF-kort. Nogle enheder med større kapacitet understøttes muligvis ikke. Formatér lagerenheden, brug filsystemet FAT32. Nogle kodningsformater kan ikke genkendes, brug venligst almindelige formatmediefiler.